

Example: 90 400 S



**CFM-value**

<b>090</b>	90 cfm	<b>tight</b>  <b>open</b>
<b>110</b>	110 cfm	
<b>125</b>	125 cfm	
<b>150</b>	150 cfm	
<b>200</b>	200 cfm	
<b>250</b>	250 cfm	
<b>300</b>	300 cfm	
<b>400</b>	400 cfm	
<b>500</b>	500 cfm	
<b>600</b>	600 cfm	
<b>000</b>	(ca. 900 - 950 cfm)	