

Beispiel

90

400

S



CFM-Wert

090	90 cfm
110	110 cfm
125	125 cfm
150	150 cfm
200	200 cfm
250	250 cfm
300	300 cfm
400	400 cfm
500	500 cfm
600	600 cfm
000	(ca. 900 - 950 cfm)

DICHT



OFFEN